



INSTALLATION INSTRUCTIONS

Part Number: HD-0900

This filter fits: See catalog for current applications

* **FREE K&N® decal** To register your warranty, please see us online at knfilters.com/register. **FREE K&N® decal ***

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modification will be required. However the following procedures **MUST** be followed to ensure the proper fit and seal of the K&N® air filter.

INSTALLATION:

1. Remove the two screws securing the bonnet. **(Fig. 1)**
2. Remove the Harley Davidson rubber spacer.

NOTE: This will be reused with the installation of the K&N® air filter. (Fig. 2)

3. Remove 4 screws securing the stock air filter to the backing plate, then remove the air filter.
4. Using a damp cloth, clean any dirt or debris from the backing plate.
5. Install the K&N® air filter onto the backing plate. When installing, ensure the air filter is oriented so the logo is on top.
Install the 4 screws to snugly secure the air filter to the backing plate.
6. Install the Harley Davidson rubber spacer that was removed in step #2. **(Fig. 2)**
7. Install the bonnet and name plate and using the two screws removed in step #1.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2