

21117/B
2014 CHEVY
SILVERADO 1500



21117/B
2014 CHEVY
SILVERADO 1500

2014 CHEVY SILVERADO 1500

Billet Series Grille

TOOLS REQUIRED:

Flat/Phillips Screw Drivers

PARTS LIST:

(8) 2" Machine Screws

(8) Wing Toggle Clip



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Grille installation

Insert the machine screws through the front of the billet grille and through the small black square tabs that are welded to the back side of the billet grilles. Install the wing clip on the end of the screws (Fig 2). Place the billet grille into the factory grille opening, use a flat screwdriver to turn the wing toggle clip so that it inserts into the factory grille behind the honeycomb (Fig 3). Hold the wing toggle clip with a screwdriver to keep it from turning while you tighten the machine screws. Repeat on the second grille. Installation complete.

