



5150 Eucalyptus Avenue Unit A
 Chino, Ca. 91710
 888.360.3696
 www.anzousa.com



Installation Manual:

Part Number: 111288 & 111287

FORD F-150 04-08 U-BAR
 STYLE PROJECTOR
 HEADLIGHTS

Tools Required:

10mm Socket

Phillip Screw Driver

Plastic Pin Remover

Completely read all the instructions before Installation

Improper installation will void warranty!

Step 1



Open the hood to begin.

Step 2



Remove the plastic pin located at the top of the OEM headlight.

Step 3



Remove the grille shroud to expose the (2) 10mm bolts on the side of the OEM headlight.

Step 4



You'll need to remove the (3) 10mm bolts located on the top and side of each headlight.

Step 5



Gently pull the headlight toward you exposing the harness. Disconnect the each connector to remove the headlight from the vehicle.

Step 6



Splice the black (ground) and green (power) wires into the parking light circuit to power the LEDs and U-Bar.

Step 7



Install the Anzo headlights by reversing steps 5-2.

Step 8



Test all functions before operating the vehicle.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to warranty policies which differ from this standard, please contact your representative for detailed category replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

