



Description: Crystal Headlight
Part Number: 121139 - 121132
Application: 97-00 Toyota Tacoma



Tools Needed
Phillips Screwdriver , 10mm Socket
and ratchet.



Remove the bolts from the top
of the grille and the two
phillips screws located at the bottom
corners.



Remove the 10mm bolt from the
top inner part of the light.



Remove the phillips screw holding
the parking lamp in.



Pull the parking lamp straight out.



Remove the two 10mm nuts
located behind the parking lamp.



Remove the 10mm bolt located
on the bottom of the light.



Pull the headlight straight out
and unplug the harness from the
back.



Install your new light by reversing
these instructions. Check
all funtions of the light before
operating on the highway.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.