



Description: Taillight  
Part Number: 211020, 211021, 211022  
Application: Chevy Silverado 03-06



Tools needed  
Phillips Screwdriver



Remove the two screw located  
inside the tailgate jam



Pull the taillight out ward



Remove the 4 light sockets by  
twisting and pulling up



Remove the stickers from the  
light sockets on the back  
of the anzo light



Install the light socket into the  
back of the Anzo light



Install the light and line up the  
screw holes. Screw the two screws  
back in.



Test all functions of the light.

*AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.*