



Description: Taillights  
Part Number: 221169, 221166  
Application: 05-09 Ford Mustang



Tools needed  
Flat head screw driver  
7/16 socket and ratchet



Remove the two plugs located  
on the trunk cover by pulling  
outward.



Using your flat head pull the 4  
push pins out that hold the  
trunk cover in.



Flip the trunk cover forward  
so you can access the 3 7/16 nuts  
that hold the tail light in.



Remove the 3 7/16 nuts



After removing the nuts pull the  
taillight straight out.



Remove the light sockets from  
the light.



If you have the upgraded harness  
for the 2010 style you will need to  
remove the old harness. Push the  
body plug out.



Unclip the harness, re route the  
new harness through the hole and  
plug it in. Again this part is only for  
the 2010 style



Twist the sockets back into place



Re-install the new taillight by  
reversing the instructions.



Check all functionality of the new  
lights before operating on any  
highway.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.