



Description: Tail Lights  
Part Number: 311047-311080-311081  
Application: 2007.5-2013 Chevy Silverado



Tools needed: Phillips  
screwdriver



Step 1: Under the vehicle bed  
unplug the wire harness for the  
tail light.



Step 2: unclip the wire from the  
plastic clips.



Step 3: Use the phillips  
screwdriver to remove the two  
screws holding in the tail light.



Step 4: Remove the tail light.



Step 5: Pull the wire out from  
under the bed.



Step 6: Peel off the protective  
cover from the resistors and  
place in the two holes onto the  
frame of the body.



Step 7: Plug the resistors in and  
the wire harness into the circuit  
board under the bed.



Step 8: Test all functions making  
sure all functions work before  
driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.