



Description: LED Taillight
Part Number: 311016 - 311017 - 311018
Application: 2002-2005 Dodge Ram (1500-2500-3500)



Tools Needed:
T8 torque screw driver



Step 1: Lower the tailgate exposing the two torque screws. Remove the screws.



Step 2: Remove the stock taillight by pulling straight out.



Step 3: Unplug the wire harness from the stock taillight housing.



Step 4: Plug the stock harness to the Anzo LED taillight.



Step 5: Make sure all functions are working properly before driving.



AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.