



Description: LED Taillight
Part Number: 311001 - 311002 - 311002 - 311100
Application: 2000-2006 Chevrolet Suburban / Tahoe



Tools needed: Phillips screwdriver



Step 1: Locate the main circuit board for the tail light underneath the vehicle located in the passenger rear.



Step 2: Unplug the middle wire harness from the circuit board.



Step 3: locate the two screws on the side of the light.



Step 4: Unscrew the two screws with the phillips screwdriver.



Step 5: Remove the tail light from the vehicle.



Step 6: Remove the protective sticker backing from the resistors and stick them inside the top tail light housing.



Step 7: plug the two resistors into the tail light.



Step 8: Put the tail light in and screw in the two screws to hold the tail light in place.



Step 9: Plug the wire harness into the circuit board and test the function of the light to make sure it is working properly

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.