



Description: Tail light  
Part Number: 311048-311092  
Application: 2007-2008 Toyota Tundra



Tools needed: T27 Torque bit  
socket.

Step 1: Use the t27 torque bit  
socket to remove the two  
screws holding in the tail light.



Step 2: Under the vehicle bed  
unplug the wire harness.

Step 3: Unclip the wire  
harness from the frame.

Step 4: Take the tail light off  
from the vehicle.



Step 5: Put in the new Anzo  
led tail light into the vehicle.

Step 6: Plug in the new Anzo  
wire harness into the original  
socket of the vehicle.

Step 7: Test all functions  
making sure they work  
properly before driving.



AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

