



Description: Tail light
Part Number: 321004-321126
Application: 1999-2001 BMW E46 3 Series 4dr



Tools needed: Flat head
screwdriver, 10mm socket



Step 1: Remove the 10 push
pins from the trunk lid.



Step 2: Unscrew the emergency
tool cover.



Step 3: Pull the cover down to
expose the tail light cover and
plug the wire harness.



Step 4: Remove the tail light cover.



Step 5: Remove the 10mm bolt
from the tail light.



Step 6: Take the inner tail light
off the car.



Step 7: Remove the outer tail light
cover off.



Step 8: Unplug the wire harness
from the cover.



Step 9: Remove the three 10mm
bolts holding the tail light in.





Step 10: Pull back the trunk lining to remove the last bolt.



Step 11: Take the tail light off.



Step 12: Put the new Anzo light in and screw it on.



Step 13: Plug the new tail light wire harness in to the original wire harness.



Step 14: Put the resistors into the bottom of the tail light housing.



Step 15: Put the new cover for the light on.



Step 16: Test all functions and make sure it's working properly before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.