



Description: Parking light
Part Number: 511048-511050

Application: 1988-1998 Chevy Fullsize Truck



Tools needed: Phillips screwdriver.

Step 1: Remove the four
Phillips screws to remove
the parking lights.



Step 2: Remove the
parking lights from the
vehicle.

Step 3: Twist off the
parking light bulb sockets.

Step 4: Twist off the bulb
from the socket.



Step 5: Twist the new Anzo
parking light bulb
connector to the socket.

Step 6: Replace the four
Phillips screws.

Step 7: Test all functions
before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.