




NO-DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1 LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2 INSERT THE PLASTIC INSERTS INTO PLACE IN THE EXISTING FACTORY HOLES ON THE UNDERSIDE OF THE HOOD. SNAP INTO PLACE WITH YOUR THUMB OR THE END OF THE SCREWDRIVER.
- 3 LINE UP THE HOOD PROTECTOR ON THE UNDERSIDE OF THE HOOD. PLACE A WASHER ON EACH OF THE MOUNTING SCREWS AND INSERT THE SCREWS THROUGH THE HOLES IN THE HOOD PROTECTOR INTO THE HOLES WITH THE PLASTIC INSERTS. **TIGHTEN JUST ENOUGH TO HOLD HOOD PROTECTOR IN PLACE.**
- 4 CENTER THE HOOD PROTECTOR ON THE HOOD AND THEN TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR. CLOSE THE HOOD CAREFULLY TO CHECK THE FIT. IF THE HOOD PROTECTOR IS NOT CENTERED, SLIGHTLY LOOSEN THE SCREWS AND MOVE IT TO ONE SIDE OR THE OTHER UNTIL CENTERED AND RE-TIGHTEN THE SCREWS.

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

CAUTION!

DO NOT ATTEMPT TO USE POWER TOOLS WHEN INSTALLING YOUR HOOD PROTECTOR. THIS WILL CAUSE THE THREADS TO STRIP INSIDE THE PLASTIC GROMMETS.



KIT CONTAINS:

HOOD PROTECTOR

5 #12 x $\frac{5}{8}$ " SCREWS

5 WASHERS

5 PLASTIC GROMMETS

TOOLS NEEDED:

PHILLIPS SCREWDRIVER