

# **SIDEWIND DEFLECTOR INSTALLATION and CLEANING**

**This product is designed to be placed on the painted metal surface of the door, just above the weather stripping.**

- 1** Clean surface thoroughly where product is to be installed with alcohol pads provided and allow to dry.
- 2** Apply the adhesive promoter to the areas where the adhesive will make contact and allow to dry.
- 3** Hold part in place and lightly mark where it will be installed.
- 4** Peel 1" of the red backing from both ends of the adhesive strip and press into place along mark.
- 5** When positioned, remove the remaining tape backing and press the part firmly along entire length of the flange using a soft cloth with a continuous rubbing motion. *BOND STRENGTH IS DEPENDENT UPON THE AMOUNT OF ADHESIVE-TO-SURFACE CONTACT. FIRM PRESSURE CREATES MAXIMUM CONTACT AND IMPROVES BOND STRENGTH. ULTIMATE BOND STRENGTH IS ACHIEVED AT 72 HOURS.*

**IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT (See Insert)!**

**IMPORTANT: Must be cleaned with a SOFT cloth and soap and water ONLY!**  
**Using abrasive cleansers, chemicals or solvents will VOID the warranty on this product.**