

NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

NOTE: A rubber bump-on is required on this application to prevent damage to the hood.

- 1 RAISE THE HOOD OF THE TRUCK AND REMOVE THE TWO RUBBER BUMPERS ATTACHED TO THE BOTTOM OF THE HOOD BY TURNING THE BUMPERS 90 DEGREES IN EITHER DIRECTION AND PULLING THEM OUT.**
- 2** Hold the hood protector against the underside of hood centered equally from the edges and familiarize yourself with the fit. Locate the areas of the hood surface where the adhesive will make contact and clean those areas with the alcohol pads provided in the hardware pack. **WARNING! Failure to thoroughly clean the adhesive contact area may result in the hood protector working loose and damaging the hood.**
- 3** Remove the red backing from the adhesive strips on the mounting tabs of the hood protector and carefully place the tabs under the hood. Center the hood protector to the hood and starting from the center tab, line up the contours of the shield to the hood and use firm pressure to adhere the adhesive to the hood. **Re-attach the rubber bumpers you removed previously.**
- 4** Remove the adhesive backing from the rubber bump-on and adhere it on the hood centered left to right and 4" up from the front edge.
- 5 RECOMMENDED: Also attach the hood protector with the self piercing screws provided.** Drill a 3/32" hole in the hood through the center of the holes on the mounting tabs. Fasten to the hood with self-tapping screws and shoulder washers. **CAUTION - DO NOT OVERTIGHTEN!**
CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

KIT CONTAINS:

HOOD PROTECTOR
6 MOUNTING SCREWS
6 SHOULDER WASHERS
1 RUBBER BUMP-ON
ALCOHOL PADS

TOOLS NEEDED:

PHILLIPS SCREWDRIVER

