



# INSTALLATION INSTRUCTIONS

## PART NUMBER: HA-3011

**This filter fits:** SEE CATALOG FOR CURRENT APPLICATIONS


**\* FREE K&N® decal To register your warranty, please see us online at [knfilters.com/register](http://knfilters.com/register). FREE K&N® decal \***

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

### INSTALLATION:

1. Remove the stock air filter.
2. Clean all sealing surfaces in the air box.
3. Install the K&N® air filter into the air box. The filter will only fit in one way.
4. With the filter sitting in the air box correctly, there are 3 screws that will secure the filter into the air box. These screws will secure the air filter while the air box cover is installed. These screws should not be over tightened. Once the screws are touching the filter, only tighten each screw one full turn.
5. Install the air box lid and tighten all screws.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



### CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.