



Completely read all the instructions before installation
Improper installation will void warranty

Step 1

Tools needed:
Phillips Screw Driver

Step 2

Remove the two phillips screws from the OEM third brake light housing.

Step 3

Carefully pull out the OEM third brake light housing from the vehicle.

Step 4

Remove the OEM third brake light by disconnecting the power source.

Step 5

Remove the Anzo third brake light out of its box.

Step 6

Install Anzo third brake light by reversing steps 2 to 4.

Step 7

Test all functions before operating the vehicle.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards are not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.