

5150 Eucalyptus Ave Unit A Chino, Ca. 91710 888.360.3696



Read complete instructions before installation! Improper installation may void warranty

Description: AUXILIARY LIGHTS
Part Number: 861123
Application: UNIVERSAL



Tools Needed 3/4 drill bit Drill Electrical wire



When you unbox your new Anzo Auxiliary lights you will see 2 pod strands and a small bag of hardware.



The bag of hardware has a sheet of 3m circles for the pods. Peel and stick to the back of the pods. A switch and screws are also supplied



Once you have 3m tape on the back of all the pods you are ready to install your lights. After you have chosen your location peel off the remaining backing.



We chose to install them as bedrail lights but these Auxiliary lights can be installed any where on the vehicle.



Since we chose to install them as bedrail lights. We removed the taillight so the wires could be ran through the underside of the vehicle up to the vehicles engine bay.

Once you have routed your wires to the engine bay along the underside of the vehicle (be sure to stay away from moving parts) the black wire will need to be connected to a ground source. Typically the negative terminal on the battery is the best place. After connecting ground you will need to run a wire (18 gauge is suitable) from a power source like the positive terminal on the battery to the inside of the cab. Locate a grommet on your firewall you can pass the power wire from the battery and the power wire from the auxiliary lights.



Hook up your switch with the power wire from the auxiliary lights and the power wire from your battery and install the switch.

If you already have a switch installed that is not being used you can use that if you prefer.



Turn your lights on and you are done.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.