



Installation Instructions
BRK2502
BRAKE ROD EXTENSION

<i>Serial No.</i>



Parts List

Ref. No.	Qty.	Part No.	Description
1	1	201-0848	1/2-20 THREADED EXTENSION
2	1	290-0334	BOX PLASTIC, 2 1/2 X 8 3/16 X 1 1/4
3	1	292-1556	BOX BACKGROUND CARD 2 1/4 X 7 3/4 BX
4	1	292-1772	LABEL, 1X3 CLAM SHELL (BAR CODE)
5	1	405-0134	INSTR, BRK2502

If the seat can't be moved forward far enough, this rod extension is available to be inserted between the brake claw and the actuator arm.

Also if there is a low steering column/dashboard which touches and interferes with the brake, this extension can be used.

