



## Installation Instructions

BRK2503

SEAT STIFFENER

Serial No.



### Parts List

Ref. No.	Qty.	Part No.	Description
1	2	270-0063	VELCRO, SEAT STIFFENER
2	1	290-0476	SEAT STIFFENER PATRIOT
3	1	292-0955	BOX, 18 X 14 X 3, WHITE, W/LOGO
4	1	292-1772	LABEL, 1X3 CLAM SHELL (BAR CODE)
5	1	405-0135	INSTR, BRK2503



To install: Put a piece of Velcro on the brake's push pads and on the outside of the seat stiffener. The brake's push pads should line up and push against the outside of the "pockets".

The seat stiffener works with any drop in tow brake on the market. It provides a larger surface area on the seat for the brake system to push against. This means you get better, more responsive braking. If you continually get a "reposition brake error" this will help solve that problem.